

# Notice

## Copyright (Copyright © 2001 HUMAX Corporation)

Not to be copied, used or translated in part or whole without HUMAX's prior consent in writing except approval of ownership of copyright and copyright law.

## Warranty

The information in this document is subject to change without notice. HUMAX does not have any responsibility for direct, indirect, accidental, necessary and other damage due to your offer or use of the information contained in this manual.

## Trademarks

VIACCESS™ is a trademark of France Telecom.

CryptoWorks (TM) is a trademark of Philips Electronics N.V.

Irdeto is a trademark of Mindport BV.

Nagravision is a registered trademark of KUNDELSKI S.A.

Conax is a trademark of Telenor Conax AS.

'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.

This receiver manufactured under license from Dolby Laboratories.

<p>Thank you for purchasing a HUMAX Satellite receiver. Please read this user manual carefully to be able to safely install, use and maintain the receiver at maximum performance. Keep this user manual next to your receiver for future reference.</p>
--

# Notice

Read this manual carefully and make sure you understand the instructions provided. For your safety, check what the result of each action will be.

## Warnings, Cautions and Notes

Throughout the whole manual, pay special attention to the following marks that indicate hazardous situations.

- **Warning**

Indicates a hazardous situation which, if not avoided, could result in serious injury.

- **Caution**

Indicates a situation which, if not avoided, could damage the equipment or other apparatus.

- **Note**

Indicates additional information to the user to make the user aware of possible problems and information of any importance to help the user to understand, to use and to maintain the installation.



To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.



This symbol indicates **dangerous voltage** inside the product that presents a risk of electric shock or personal injury.



This symbol indicates important instructions accompanying the product.

# Safety and Warning

This receiver has been manufactured to comply with international safety standards. Please read the following safety precautions carefully.

## Safety Instructions and Precautions

### 1. MAINS SUPPLY

90 - 250V AC 50/60Hz

Operate this product only from the type of power supply indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your local power company. Disconnect the product from the mains before you start any maintenance or installation procedures.

### 2. OVERLOADING

Do not overload a wall outlet, extension cord or adapter as this may result in electric fire or shock.

### 3. LIQUIDS

The product should not be exposed to any liquids such as dripping or splashing. In addition, no objects filled with liquids, such as vases, should be placed on the apparatus.

### 4. CLEANING

Disconnect the product from the wall outlet before cleaning. Use a light damp cloth (no solvents) to dust the product.

### 5. VENTILATION

The slots on top of the product must be left uncovered to allow proper airflow to the unit. Do not stand the product on soft furnishings or carpets. Do not stack electronic equipments on top of the product.

### 6. ATTACHMENTS

Do not use any unsupported attachments as these may be hazardous or cause damage to the product.

### 7. CONNECTION TO THE SATELLITE DISH LNB

Disconnect the product from the mains before connecting or disconnecting the cable from the satellite dish. Failure to do so can damage the LNB.

### 8. CONNECTION TO THE TV

Disconnect the product from the mains before connecting or disconnecting the cable from the satellite dish. Failure to do so can damage the TV.

### 9. EARTHING

The LNB cable must be buried in the ground. The buried cable of the system must comply with SABS 061.

# Safety and Warning

## 10.LOCATION

Place the product indoors to avoid exposing it to lightening, rain or sun.

Do not place it near a radiator or heat register.

Make sure it has more than 10 cm clearance from any appliances susceptible to electromagnetic influences, such as a TV or a VCR.

Do not block these openings with any object, and do not place the product on a bed, sofa, rug, or other similar surface.

If you place the product on a rack or bookcase, ensure that there is adequate ventilation and that you have followed the manufacturer's instructions for mounting.

Do not place the product on an unstable cart, stand, tripod, bracket or table from where it can fall. A falling product can cause serious injury to a child or adult, and serious damage to the appliance

## 11.LIGHTNING, STORM, or NOT IN USE

Unplug the product from the wall outlet and disconnect the antenna during a thunderstorm or when left unattended and unused for long periods of time. This will prevent damage to the unit due to lightning and power-surges.

## 12.EXTRANEIOUS OBJECTS

Do not insert anything through the openings in the unit, where they can touch dangerous voltage points or damage parts.

## 13.REPLACEMENT of PARTS

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer, or those that have the same characteristics as the original part. Unauthorized substitution may result in additional damage to the unit.

## Warning

1. Follow these directions in order not to damage the power cord or plug.  
Do not modify or process the power cord or plug arbitrarily.  
Do not bend or twist the power cord too much.  
Make sure to disconnect the power cord with the plug held.  
Keep heating appliances as far as possible from the power cord in order to prevent the cover vinyl from melting.
2. Follow these directions. Failure to follow one of them may cause electrical shock.  
Do not open the main body.  
Do not insert metals or inflammable objects inside the product.  
Do not touch the power plug with wet hands.  
Disconnect the power cord in case of lightning.
3. Do not use the product when it is out of order. If you continue to use the product when defective, a serious damage can be caused to it. Make sure to contact your local product distributor if the product is out of order.
4. Please do not insert metal or alien substance into the slots for the modules and smart cards. In doing so can cause damage to the STB and reduce its life span.

<b>1. Before Using the Receiver</b>	<b>GB8</b>
1.1 Package Contents	GB8
1.2 Front Panel	GB9
1.3 Rear Panel	GB9
1.4 Remote Control	GB10
<b>2. Setup</b>	<b>GB12</b>
2.1 Connecting the Antenna	GB12
2.2 Powering On	GB12
<b>3. Installation Wizard</b>	<b>GB13</b>
3.1 Language	GB13
3.2 Area Setting	GB13
3.3 Antenna Setting	GB14
3.4 Automatic Search	GB15
3.5 Time Setting	GB15
<b>4. Basic Operation</b>	<b>GB16</b>
4.1 Switching Channel	GB16
4.2 Volume Control	GB16
4.3 Change the Subtitle Language	GB16
4.4 Change a Audio Language	GB17
4.5 Programme Information (I- plate)	GB17
4.6 Option List	GB19
<b>5. Channel List</b>	<b>GB22</b>
5.1 Displaying and Switching Channel List	GB22
5.2 Changing Channel List Group	GB23
5.3 Edit Channels	GB24
5.4 Edit Favourite Channels	GB27
5.5 Channel Looping Mode	GB30

<b>6. Programme Guide</b>	<b>GB31</b>
6.1 Viewing Programme Guide Information	GB31
6.2 Finding a Programme	GB33
6.3 Viewing Reserved Programme	GB34
<b>7. Setting Preferences</b>	<b>GB36</b>
7.1 Parental Control	GB36
7.2 Language Setting	GB38
7.3 Time Setting	GB39
7.4 Schedule	GB41
7.5 A/V Control	GB41
7.6 UHF	GB43
7.7 Miscellaneous	GB43
<b>8. Installation</b>	<b>GB44</b>
8.1 Antenna Setting	GB44
8.2 Automatic Search	GB46
8.3 Manual Search	GB48
8.4 Other Search	GB51
8.5 Default Setting	GB55
<b>9. Software Upgrade</b>	<b>GB56</b>
9.1 OTA (Over the Air)	GB56
9.2 Software Update from PC	GB60
<b>10. System Information</b>	<b>GB61</b>
10.1 Status	GB61
10.2 Signal Detection	GB61


<b>11. Games</b>	<b>GB62</b>
<b>12. Menu Map</b>	<b>GB63</b>
<b>13. Trouble Shooting</b>	<b>GB64</b>
13.1 Trouble Shooting	GB64
13.2 Error Message	GB65
<b>14. Specification</b>	<b>GB66</b>
<b>15. Glossary</b>	<b>GB68</b>
<b>16. Service and Support</b>	<b>GB69</b>

# 1. Before Using the Receiver

This chapter provides detailed instructions on the product and its accessories.

## 1.1 Package Contents


Please check all package contents before using your product.



**Batteries (2)**




**Remote Control Unit (1)**



**User's Manual (1)**

**Note:** Since faults may occur if the remote controller is being left without a battery for a long time, always keep the battery inserted in the remote controller.


## 1.2 Front Panel



### 1. Display

Turns on red light when the product is in Standby mode.  
Turns on green light when it is in operation.

## 1.3 Rear Panel



### 1. LNB IN

Connects a satellite antenna cable.

### 2. RS-232C

Connects to your PC to upgrade product's software programme.


### 3. TV SCART

Connects a TV SCART cable.

# 1. Before Using the Receiver

## 1.4 Remote Control

The available remote controller may vary depending on the regions and models.



- 1. SOURCE
- 2. TV/RADIO
- 3. NUMERICAL  
BUTTONS
- 4. LIST
- 5. BACK

- 6. ARROW BUTTONS
- 7. OPT+ (OPTION)
- 8. SOUNDTRACK
- 9. CH-/CH+ and  
PAGE-/PAGE+
- 10. MENU
- 11. G (Game)

- 12. STANDBY
- 13. GUIDE
- 14. EXIT
- 15. OK
- 16. FREEZE
- 17. SUBTITLE
- 18. V-/V+
- 19. i (INFORMATION)
- 20. MUTE

# 1. Before Using the Receiver

## 1. SOURCE

Selects the input source between TV and satellite receiver.

## 2. TV/RADIO

Switches between TV and Radio modes.

## 3. NUMERICAL BUTTONS

Enters a TV/Radio channel number or menu option number.

## 4. LIST

Displays the channel list.

## 5. BACK

Returns to the previous menu and screen.

## 6. ARROW BUTTONS

Changes the channel or move the cursor to the up, down, left or right menu option.

## 7. OPT+ (OPTION)

Displays the channel attributes during watching a programme.

## 8. SOUNDTRACK

Displays the Soundtrack.

## 9. CH-/CH+ and PAGE-/PAGE+

Changes the Channel or Page.

## 10.MENU

Displays the main menu.

## 11.G (Game)

Displays the Game.

## 12.STANDBY

Switches between Operation and Standby modes.

## 13.GUIDE

Displays the Programme Guide.

## 14.EXIT

Exits the main menu or Guide screen.

## 15.OK

Selects a menu, or confirms the selected operation. And displays the channel list during watching a programme.

## 16.FREEZE

Freezes the TV screen you are watching. Play the audio continuously.

## 17.SUBTITLE

Changes the subtitle language.

## 18.V-/V+

Adjusts the audio volume.

## 19.i (INFORMATION)

Displays the information about the channel and programme.

## 20.MUTE

Pauses the audio temporarily. That is, volumes on/off temporarily.

## 2. Set-up

This chapter describes how to set up the receiver. Select the most appropriate procedure depending on your requirements.

**Note:** If you encounter any problem when setting up the receiver, please contact your local product distributor.

### 2.1 Connecting the Antenna


#### 1. Connecting TV and VCR

This is the most simple set-up mode.



### 2.2 Powering On

1. Connect the power cord of the receiver to a wall outlet.



2. Power on by pressing the **STANDBY** (⏻) button at Remote Controller. The Standby LED indicator is turned on Green.



## 3. Installation Wizard

When powering on your receiver for the first time after purchasing, the Installation Wizard is automatically started.

You can easily set-up using simple organisation and options, and watch the broadcasting after completing the set-up procedure. You can select items using the **NUMERICAL** (0-9) buttons.

**Note:** If you press the **BACK** (⏪) button or select **Back** and press the **OK** (⏹) button while running the **Installation Wizard**, you can return to the previous screen.

### 3.1 Language

You can select Menu, Audio, and the subtitle language.

Select the appropriate language from the list using the ▲/▼ button and press the **OK** (⏹) button to save the selected language as a default language and move to the next step **Antenna Setting**.



### 3.2 Area Setting

You can select area.

Select the appropriate area from the list using the ▲/▼ button and press the **OK** (⏹) button.



# 3. Installation Wizard

## 3.3 Antenna Setting

You can set the antenna's properties to watch the programme.

1. Select the **Satellite** which the antenna points to. Press the **OK** (OK) or **▶** button to display satellites list. Select satellite using the **▲/▼** button, and press the **OK** (OK) button.
2. Set the **LNB Frequency**.

Press the **OK** (OK) or **▶** button to display LNB frequency list. Select LNB frequency using the **▲/▼** button, and press the **OK** (OK) button.

If you cannot find the LNB frequency value from the list, select **User Define**, manually enter the frequency using the **NUMERICAL** (0-9) button, and then press the **OK** (OK) button.

**Note:** When using Universal LNB, select **Universal** for LNB Frequency which is 9750/10600(MHz). Also, if you select **Universal**, 22KHz tone value is disabled.

3. Set up **22kHz Tone**.

Select **22kHz Tone** using the **▲/▼** button, and press the **OK** (OK) or **▶** button to change the setting.

When using 22kHz tone switch, select **Enable**. Otherwise, select **Disable**.

4. Select **DiSEqC** switch.

Select **DiSEqC** using the **▲/▼** button, and press the **OK** (OK) or **▶** button to display DiSEqC Switch List. Select DiSEqC Switch using the **▲/▼** button and then press the **OK** (OK) button.

5. When you complete the setting, select **Next** using the **▲/▼** button and press the **OK** (OK) button to start Automatic Search.



### Note:

- If the antenna is correctly set up, the level at signal strength bar and quality bar, which are located at the bottom of the screen, are generally moved up.
- If you encounter any problems or questions when setting up the antenna, please contact your local product installer or distributor.

### 3.4 Automatic Search

You can automatically search for satellites according to the Antenna Setting.

Please wait for finishing the Automatic Search. If you want to stop the Automatic Search, press the **OK** (OK) button.

If the Automatic Search is stopped or finished, the searched result is automatically saved and go to the next step.



### 3.5 Time Setting

You can set the current time.

Press the **OK** (OK) or ► button to display the values for **GMT Offset**.

Select the appropriate GMT Offset value using the ▲/▼ button and press the **OK** (OK) button to set the current time. Check the current time at the bottom of the screen to see if it's correctly set up. Then select **Next** using the ▲/▼ button and press the **OK** (OK) button to finish Installation Wizard.



**Warning:** Press the **EXIT** (EXIT) button to save the previous input information and exit the Installation Wizard when running the Installation wizard. If you exit the Install Wizard without fully completing the setting procedures, you may not watch any broadcasting normally. In this case, you can use the **Menu-Installation-Antenna Setting** and **Channel Search** menu to configure your receiver as you like.

## 4. Basic Operation

This chapter describes functions such as switching channel, volume control, and basic features for watching programmes.

### 4.1 Switching Channel

You can switch the current channel using one of the following methods.

1. Press the **CH-/CH+** (⊖/⊕) button.
2. Enter your desired channel numeric using the **NUMERICAL** (0-9) buttons to move to the channel directly.
3. Press the **TV/RADIO** (⊙) button to switch between TV channel and Radio channel.

**Note:** You can switch channel using the channel list or programme guide. Please refer to Chapter 5 and 6 for more information.

### 4.2 Volume Control

1. Press the **V-/V+** (⊖/⊕) buttons to adjust the audio volume.
2. Press the **MUTE** (⊘) button to stop the sound temporarily.

**Note:** The mute function keeps enabled while you change the channel.

### 4.3 Change the Subtitle Language

If the current programme provides Subtitle information, you can select the language for the Subtitle.

1. Press the **SUBTITLE** (⊞) button to display the subtitle language list.
2. Select your desired subtitle language using the **▲/▼** button, and press the **OK** (⊙) button. Then the subtitle will be displayed in the selected language at the bottom of the screen.
3. Select **OFF** from the subtitle language list not to display subtitle from the screen.



**Note:** You can select a default subtitle language by selecting **MENU - Preferences - Language Setting - Subtitle Language**.

## 4.4 Change an Audio Language

If the current programme is available in multiple audio languages, you can select the language that you wish to listen in.

1. Press the **SOUNDTRACK** (🔊) button to display the **soundtrack list**.
2. Select your desired audio language using the ▲/▼ button to change Audio immediately.
3. Select Audio Direction (left, right, stereo) using the ◀/▶ button.



### Note:

- You can select your desired default audio language by selecting **MENU - Preferences - Language Setting - Audio Language**.
- If the programme is Dolby digital one, you cannot set the audio direction such as left, right, and stereo.
- If you select **Dolby** by selecting **MENU - Preferences - Language Setting - Audio Priority**, Dolby Digital programme is automatically broadcasted with Dolby digital audio without considering default audio language.

## 4.5 Programme Information (I-plate)

Programme information is always displayed for a specific period of time whenever you switch channels. You can view the programme information by pressing the **i** (i) button while watching a programme. Press the **EXIT** (EXIT) button to hide the I-plate.

# 4. Basic Operation

## 1. General Information

General Information is displayed as follows on the screen.



1. Channel number and channel name

2. Programme name

3. Icons

Displayed only if this programme is reserved.

Represents parental level. It indicates the minimum level of ages that the programme is targeted at.

Displayed only when the channel is a locked channel.

Displayed only when the channel is a scrambled channel.

Displayed only when subtitle information is available.

Displayed only when there is any teletext information.

Displayed only when the programme is a dolby digital one.

4. Current time

5. Detail programme information: displayed if detailed programme information is provided.

6. Signal strength and signal quality : indicates signal level.

7. Satellite name or channel change mode : If you select **All channels** by selecting **MENU - Edit channels - Channel Change Mode**, the Satellite name, which the current channel is belonged to, is displayed; if you select **Within the current channel list**, the channel list, which you selected, is displayed.

8. Programme broadcasting time and progress bar: displays programme playing time and progress bar.

9. Next programme Information : displayed if next programme information is provided. Press the button to display the next programme information.

**Note:** If there is no available programme information, programme information is not displayed.

## 2. Detail Programme Information

You can see detailed information about the current programme. Press the **i** (i) button where I-plate is displayed to view detailed information.

**Note:**

- Press the **i** (i) button again to hide the information box.
- If the Detail information is more than one page, use **▲/▼** button to move to the previous or next page.



## 4.6 Option List

You can view and confirm detailed information about the current channel and change the information in necessary.

**Note:** Press the **OPT+** (OPT) button when the channel list is displayed to view **Option List**. Then the following functions in the option list are performed to the current channel where cursor is located.

### 1. Add a channel to favourite group

You can add current channels to the favourite group immediately. Also, you can add a channel to multiple Favourite groups.

1. Press the **OPT+** (OPT) button.
2. Select **Favourite** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.



3. Select **favourite group** using the **▲/▼** button and press the **OK** (OK) button to register for favourite group.
4. Press the **OK** (OK) button again on the selected **Favourite Group** to release the registered channel.
5. Move to the parent menu using the **◀** button to save the changes automatically.



**Note:** For detailed information about how to change Favourite Group's name and how to register Favourite Channel for the whole channels, refer to **Chapter 5**.

# 4. Basic Operation

## 2. Lock/Unlock a Channel

You can lock or unlock the current channel while watching a programme.

1. Press the **OPT+** (Ⓞ) button.
2. Select **Lock** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
3. Select **Lock** option using the **▲/▼** button, and press the **OK** (Ⓞ) button.
4. Select **Unlock** option using the **▲/▼** button, and press the **OK** (Ⓞ) button.
5. You will be prompted to enter your password. Enter your password to unlock the channel.
6. Move to the parent menu using the **◀** button to save the changes automatically.

**Note:** When switching to the locked channel, you must enter the password to watch a programme.



## 3. Delete a Channel

You can delete the current channel while watching a programme.

1. Press the **OPT+** (Ⓞ) button.
2. Select **Delete** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
3. Select **Yes** in the confirmation message and press the **OK** (Ⓞ) button.
4. Enter password using the **NUMERICAL** (0–9) buttons to delete the current channel and move to the next channel.



## 4. Channel Information

You can display detailed information about the current channel while watching a programme.

1. Press the **OPT+** (OPT) button to display channel information automatically.
2. Select Information using the **▲/▼** button to display channel information automatically.



The following information is displayed on the Information.


- |                 |   |
|-----------------|---|
| <b>1st Line</b> | Provider name   |
| <b>2nd Line</b> | Satellite and CAS type  |
| <b>3rd Line</b> | Transponder Information for the channel (Frequency, Polarisation, Symbol rate, FEC) |
| <b>4th Line</b> | Video PID, Audio PID ,PCR PID(Packet Identification)                                |
| <b>5th Line</b> | Network ID(NID), Service ID(SID)  |




## 5. Channel List

5 types of channel lists are provided for easy and quick channel finding.

- TV** The list of all TV channels with 2 sub-groups: one is sorted by channel number, the other is sorted by channel name.
- Radio** The list of all Radio channels with 2 sub-groups: one is sorted by channel number, the other is sorted by channel name.
- Favourite** The list of the favourite channels with 5 sub-groups that you can organise channels by your private taste.
- Satellite** The lists of channels classified by satellites. The number of subgroup is decided by the result of channel search.



### 5.1 Displaying and Switching Channel List

You can display channel list using **LIST** () button while watching a programme to display the channel list.

1. Press the **LIST** () button while watching a programme to display the selected channel list.
2. Select your desired channel using the **▲/▼** button and press the **OK** () button to change the channel.
3. Enter the channel numeric directly using the **NUMERICAL** (0~9) buttons to move cursor into your desired channel. And then press the **OK** () button to change into the selected channel.




#### Note:

- If there are multiple channels, press the **PAGE-/PAGE+** () button to move by channel.
- Whenever you press the **TV/RADIO** () button while the channel list is displayed, the channel list will be switched between TV and Radio channel list.

## 5.2 Changing Channel List Group

You can select channel list by group.

1. Press the ► button while the channel list is displayed to view the group list.
2. Select your desired channel group using the ▲/▼ button to display its sub-groups.
3. Press the OK (OK) or ► button, select your desired sub-group using the ▲/▼ button, and then press the OK (OK) button.
4. The channel list for the selected sub-group is displayed.



### Note:

- The sub-group of favourite channel list may exist or not depending on your configuration. And The sub-group of Scramble channel list may exist or not depending on the result of Channel Search.
- If **Within the Current Channel List** option is selected from **MENU - Edit channels - Channel Change Mode menu**, you can only change programme within the selected channel list using the CH+/CH- (CH+/CH-) while you are watching a programme.

# 5. Channel List

## 5.3 Edit Channels

You can edit all channels or each channel by channel list group.

1. Press the **MENU** (MENU) button.
2. Select **Edit Channels** using the ▲/▼ button, and press the **OK** (OK) or ► button.
3. Select **Edit Channel List** using the ▲/▼ button, and press the **OK** (OK) or ► button.
4. You will be prompted to enter your password. Enter your password using **NUMERICAL** (0~9) button.



### Note:

- Press the **BACK** (BACK) or ◀ button to save the changes and return to the previous menu. Press the **MENU** (MENU) or **EXIT** (EXIT) button to exit the Menu screen.
- You can easily navigate all menus using the assigned numeric for each menu. Press the **MENU - 2 - 1** in order at remote controller to select **Edit Channel List** menu.



## 1. Select a Channel Group

You can select the channel list group to edit. TV or Radio, and the sub-groups from the channel search for scramble channel lists are included as channel list groups.

1. Press the **OK** (OK) or ► button in **Group** to display **channel list group**.
2. Select your desired **channel list group** using the ▲/▼ button, and press the **OK** (OK) button.



### Note:

- Press the **TV/RADIO** (TV/RADIO) button to move to **TV or RADIO channel list** directly.
- For editing **Favourite channel list**, move to **MENU - Edit Channels - Edit Favourite Channels** menu.

## 2. Delete Channels

You can delete one or more channels.

1. Move the cursor to the channel list using the ▲/▼ button.
2. Select your desired channel, and then press the **OK** (OK) button . You can select multiple channels.
3. Select **Delete** in the right using their the ► button, and press the **OK** (OK) button.



## 3. Lock/Unlock Channels

You can lock or unlock one or more channels.

1. Move the cursor to the channel list using the ◀/▶ button.
2. Select your desired channel, and then press the **OK** (OK) button. You can select multiple channels.
3. Select **Lock** in the right using the ► button, and press the **OK** (OK) button.



### Note:

- Only if locked channel(s) is selected or all channels are locked, **Lock** is switched into **Unlock**. When you press **Unlock**, locked channel is switched into unlocked channel.
- Enter password using the **NUMERICAL** (0–9) button to watch locked channel.



# 5. Channel List

## 4. Move Channels

You can move one or more channels into your desired location, which changes the channel number accordingly.

1. Move the cursor to the channel list using the ◀/▶ button.
2. Select your desired channel, and then press the **OK** (OK) button. You can select multiple channels.
3. Select **Move** in the right using the ▶ button, and press the **OK** (OK) button. Then the selected channel(s) disappears from the channel list for a while.
4. Move the cursor to the desired location in the channel list using the ▲/▼ button, and press the **OK** (OK) button.
5. The selected channel(s) is moved to the selected location in order.



**Note:** **Move** is available only for TV or radio channel list.

## 5. Rename a Channel

You can change the channel name as you like.

1. Move the cursor to the channel list using the ◀/▶ button.
2. Select your desired channel, and then press the **OK** (OK) button. You can select only one channel
3. Select **Rename** in the right using the ▶ button, and then press the **OK** (OK) button.
4. Enter a channel name directly using the keyboard displayed on the screen.
5. When finishing entering channel name, select **OK**, and press the **OK** (OK) button.



## 6. Select/Unselect All Channels

You can select/unselect all channels at a time.

1. Select **Select All** in the right and press the **OK** (OK) button to select all channels.
2. Select **Unselect All** in the right and press the **OK** (OK) button to unselect all the selected channels.

## 5.4 Edit Favourite Channels

You can edit Favourite channel or Favourite channel list.

1. Press the **MENU** (MENU) button.
2. Select **Edit Channels** using the **▲/▼** button, and press the **OK** (OK) button.
3. Select **Edit Favourite Channels** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.











### Note:

- Press the **BACK** (BACK) or **◀** button to save the changes and return to the previous menu. Press the **MENU** (MENU) or **EXIT** (EXIT) button to exit the Menu screen.
- You can easily navigate all menu items using the assigned numerical button for each menu. Press the **MENU - 2 - 2** in order on the remote controller to select the **Edit Favourite Channels** menu.




The buttons for editing the Favourite channel list are described in the following table.



# 5. Channel List

-  Add Adds Favourite channel.
-  Remove Removes from the Favourite channel.
-  TV/Radio Switches between TV and Radio channel list.
-  Fav.Group Changes Favourite channel list group.
-  Move Moves the order of channel list within the Favourite channel list.
-  Rename Renames the name of Favourite channel list.
-  Sort Sorts channels by number or name in all TV/Radio channel list.
-  Unselect All Unselect all the selected channel.

## 1. Add/Remove favourite channels

You can add favourite channel(s) to a specific Favourite channel list or remove the added favourite channel(s) from the list.

1. Select **Favourite Group** using  .
2. Select your desired channel(s) in all TV/Radio channel list, and press  to add Favourite channel(s).
3. Select your desired channel(s) in Favourite channel list, and press  to remove Favourite channel(s).


**Note:** You can switch between TV and Radio channel list using **TV/RADIO** () button at remote controller or  .









## 5. Channel List

### Change between TV and Radio channel list

You can add not only TV channel(s) but also Radio channel(s) to Favourite channel list. Press  to switch all channel list into TV or Radio channels.




**Note:** You can also change into TV or Radio channel by pressing **TV/RADIO** () button at remote controller.

### Select a favourite channel list

You can select your desired Favourite channel list to edit. Press  to display the Favourite channel list. Then select your desired channel list using the  button, and press the **OK** () button.



### Sort a channel list







You can sort all TV or Radio channel lists by channel number or name for easy Favourite channel searching. If channel lists are sorted by channel number,  is displayed. When you press this button, all the channel lists are sorted by name. Or, if channel lists are sorted by channel name,  is switched into . Press this button to order channels by number.

### Unselect all the selected channels


Press  button to unselect all the selected channel.

## 5.5 Channel Change Mode

You can change the channel either in the group or in the entire channels while watching a programme.

1. Press the **MENU** () button.
2. Select **Channel Change Mode** using the  button, and press the **OK** () or  button.
3. Select **All Channels** or **Within the current channel list** using the  button, and press the **OK** () button.



**Note:** When **Within the current channel list** is selected, you can only change the channel within the current channel list using the **CH-/CH+** () buttons. To change the channel in another channel list in which the current channel list is not located, change the channel list group or select **All channels** option.

## 6. Programme Guide

The Programme Guide displays programme information about each channel, based on the date and time. You can also schedule your recording using the information given.

### 6.1 Viewing Programme Guide Information

You can view programme information for all channels.

1. Press the **GUIDE** (GUIDE) button.
2. Move to previous or next programme within the same channel using the **▲/▼** button.
3. Move to another desired channel using the **▲/▼** button. If there are multiple channels, use **PAGE-/PAGE+** (CH-/CH+) button to move to channels by page. Also, you can enter your desired channel number using the **NUMERICAL**(0–9) button on the remote controller to move to the channel directly.



4. Select your desired programme, and press the **OK** (OK) button. Then you can watch the programme if it is on air, or you can reserve it if it is the future programme.
5. Press the **i** (i) button in the selected programme to view **detailed information** for the selected channel.

### 1. Viewing Guide Information by Channel List Groups

You can view programme information for desired channel list by groups.

1. Press the **GUIDE** (GUIDE) button.
2. Press the **Red** button to display the channel list group.
3. Select your desired channel list group using the **▲/▼** button to display the appropriate sub-group.
4. Move the cursor to the sub-group using the **▶** button, select your desired sub-group using the **▲/▼** button, and then press the **OK** (OK) button.
5. The Programme Guide for selected channel list is displayed.



# 6. Programme Guide

## 2. Viewing Programme Information Using Time Bar

You can quickly search for your desired time zone using the Time bar.

1. Press the **GUIDE** (GUIDE) button.
2. Press the **Green** button to display **Time Bar**.
3. Select the **Time Bar** button using the **▲/▼** button, and press the **OK** (OK) button to move as your desired amount of time. If you press the button repeatedly, the same operation is repeated.



4. Each button functions as follows.

**Now** Moves to the current programme where the cursor is located.

◀ Moves to the previous programme or 30 minutes before.

▶ Moves to the next programme or 30 minutes after.

◀◀ Moves to 2 hours before.

▶▶ Moves to one day before.

◀Day Moves to one day before.

Day▶ Moves to one day after.

5. Select **▲** button and press the **OK** (OK) button to exit the Time Bar.

**Note:** Guide provides programme information from the previous day to the next 7 days.

## 3. Reserving (Reserving a Watching)

You can automatically reserve your desired programme by selecting the scheduled programme and pressing the **OK** (OK) button.

1. Select the desired programme and press the **OK** (OK) button. The following message will be displayed.
2. Select **Yes** and press the **OK** (OK) button to reserve the programme. When a reservation has been completed, the **TV** icon is displayed on the reserved programme.
3. Select **No** and press the **OK** (OK) button not to reserve the programme.



4. If the channel is locked, parental controlled or restricted by watching time, you will be prompted to enter your Password. Enter your Password to complete the reservation.

## 6.2 Finding a Programme

You can find your desired programme by programme name or genre easily.

1. Press the **GUIDE** (GUIDE) button.
2. Press the **Blue** button to display *Find* screen.
3. Enter the programme name directly using the keyboard displayed on the screen.



**Note:** If you select *Previous* or *Next* on the Keyboard displayed on the screen and press **OK** (OK) button, the keyboard layout is switched.

4. When completing entering programme name, select the *Find* and press the **OK** (OK) button.
5. Select *By Genre* and press the **OK** (OK) button to search programme by genre.
6. Select your desired genre and press the **OK** (OK) button.



7. If you select your desired programme from the *Found Programme List* screen and press the **OK** (OK) button, you can watch the programme if it is on air, or you can reserve your recording if it is the future programme.



**Note:** The *Found Programme List* may differ depending on the provided programme information.

## 6. Programme Guide

### 6.3 Viewing Reserved Programme

You can add or edit watching-reserved programme by schedule screen.

1. Press the **GUIDE** (GUIDE) button.
2. Press the **Yellow** button to display the **Schedule** screen.
3. Select the scheduled programme and press the **OK** (OK) button to edit the reservation information.
4. Select a blank list and press the **OK** (OK) button to add a new watching schedule.



#### 1. Editing a Reserved Programme

1. Change the reserved Start Time using the ◀/▶ button and the **NUMERICAL** (0~9) button.
2. Change the reserved End Time using the ◀/▶ button and the **NUMERICAL** (0~9) button.
3. Change the Repeat mode using the ◀/▶ button. The options are **Once**, **Daily**, and **Weekly**.
4. Change the Lock mode using the ◀/▶ button.
5. Select the **Delete** and press the **OK** (OK) button to delete the reserved programme.
6. Select the **Cancel** and press the **OK** (OK) button to cancel the editing.
7. Select the **Save** and press the **OK** (OK) button to complete the editing.



**Note:** **Lock** mode is displayed only for the product with hard disk drive.

## 2. Adding a Reservation

1. Enter your desired channel number using the **NUMERICAL** (0–9) button. The channel name is automatically displayed by channel number.
2. Enter your desired Start Time using the ◀/▶ button and the **NUMERICAL** (0–9) button.
3. Enter your desired End Time using the ◀/▶ button and the **NUMERICAL** (0–9) button.
4. Select one of **Repeat** mode options among **Once**, **Daily**, and **Weekly** using the ◀/▶ button.
5. Select **Lock** mode using the ◀/▶ button.
6. Select the **Save** and press the **OK** (OK) button to complete entering.
7. Select the **Cancel** and press the **OK** (OK) button to cancel the reservation.
8. If the channel is locked, restricted by watching time, you will be prompted to enter your Password to complete the reservation.



### Note:

- **Lock** mode is displayed only for the product with hard disk drive.
- You can reserve up to 20 programmes.
- If your desired programmed is already reserved programme, adjust the reservation appropriately.
- You can set censorship, watching time, and all other items suitable for your environment.

### Note:

- Press the **BACK** (BACK) or ◀ button to save the changes and return to the previous menu. Press the **MENU** (MENU) or **EXIT** (EXIT) button to exit the Menu screen.
- You can easily select all menu items using the assigned numerical button for each menu.

# 7. Setting Preferences

## 7.1 Parental Control

You can set parental control for each programme and watching time. You can also change your password.

1. Press the **MENU** (Ⓜ) button.
2. Select the **Preferences** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
3. Select the **Parental Control** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
4. When a prompting message is displayed to request your password, enter the password using the **NUMERICAL** (0~9) button.



## 1. Setting Censorship

**Censorship Classification** allows you to block programmes according to the age level you have set.

1. Select the **Censorship Classification** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
2. Select your desired **Age Level** using the **▲/▼** button, and press the **OK** (Ⓞ) button.



**View All** All programmes can be watched because there is no age limitation.

**7** Programmes are blocked for children under the age of 7.

**12** Programmes are blocked for children under the age of 12.

**15** Programmes are blocked for children under the age of 15.

**18** Programmes are blocked for children under the age of 18.

**Lock All** Programmes are blocked without considering the age level.

**Note:** You have to enter Password to watch the programme which is blocked by the age level.

## 2. Setting Allow Watch Time

You can block programmes according to the watching time for all the channels.

1. Select the **Allow Time Control** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select Enable or Disable the **Allow Time Control** using the ▲/▼ button, and press the **OK** (OK) or ► button.

**Disable** You can watch whenever you want regardless of Allow Time.

**Enable** You can watch only while the time specified by Allow Time.

3. When you have selected **Enable**, set the Start and End Time using the **NUMERICAL** (0~9) buttons, and press the **OK** (OK) button.
4. If you wish to cancel the entered time, select the **Cancel** button, and press the **OK** (OK) button.



**Note:** Once the setting has been completed, you can watch programme only while the time specified by Allow Time. Or you should enter the Password to watch any programme during unspecified time.

# 7. Setting Preferences

## 3. Change Password

You can change the existing password into new one.

1. Select **Change Password** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Enter **New Password** using the **NUMERICAL** (0~9) button, and select **OK** and press **OK** (OK) button.
3. Enter the New Password again to confirm the **Verify Password**, and select **OK** and press the **OK** (OK) button.



**Note:** The Default Password is **0000**. If you have forgotten your Password, please contact your local product distributor.

## 7.2 Language Setting

You can set Language for Menu, Audio, and Subtitle.

1. Press the **MENU** (MENU) button.
2. Select **Preferences** using the ▲/▼ button, and press the **OK** (OK) or ► button.
3. Select **Language Setting** using the ▲/▼ button, and press the **OK** (OK) or ► button.



### 1. Menu/Audio/Subtitle Language

You can set the language for Menu, Audio and Subtitle. Default language is English.

1. Select **Menu/Audio/Subtitle Language** using the ▲/▼ button.
2. Press the **OK** (OK) or ► button to display the available Language List.
3. Select your desired language using the ▲/▼ button, and press the **OK** (OK) button.

### 2. Audio Priority

This receiver doesn't provide this function.

### 3. Subtitle Display

You can select whether or not to display the Subtitle if provided.

1. Select **Subtitle Display** using the ▲/▼ button.
2. Select your desired option using the OK (OK) or ► button. option.

**Auto** Subtitles are displayed automatically in the predefined subtitle language.

**Manual** Subtitles are displayed in the language when you select the subtitle language by pressing the **SUBTITLE** (SUB) button at remote controller.

### 4. Subtitle Font

You can select the Subtitle font.

1. Select **Subtitle Font** using the ▲/▼ button.
2. Select your desired option using the OK (OK) or ► button.

**Variable** Uses the horizontally variable Subtitle Font.

**Fixed Font** Uses the fixed Subtitle Font.

## 7.3 Time Setting

You can specify the current time and Power On/Off time.

1. Press the **MENU** (MENU) button.
2. Select **Preferences** using the ▲/▼ button, and press the OK (OK) or ► button.
3. Select **Time Setting** using the ▲/▼ button, and press the OK (OK) or ► button.



# 7. Setting Preferences

## 1. Setting Current Time

You can set the GMT Offset for current time.

1. Select **GMT Offset** using the ▲/▼ button.
2. Press the **OK** (OK) or ► button to display **GMT** list. GMT is changed by from 30 minutes to 1 hour.
3. Select your GMT offset using the ▲/▼ buttons, and press the **OK** (OK) button.



**Note:** The current time is set automatically whenever GMT Offset changes.

## 2. Power On Control

You can set the time when the product is automatically powered on.

1. Select **Power On Control** using the ▲/▼ button.
2. Select either **Enable** or **Disable** the Power On Control using the ► or **OK** (OK) button.

**Enable** Uses the Power On Control and sets the Power On time.

**Disable** Not uses the Power On Control.

3. When you have selected **Enable**, enter the **Channel No** and using the **NUMERICAL** (0-9) buttons, and select **OK** and press the **OK** (OK) button.



## 3. Power Off Control

You can set the time when the product is automatically powered off.

1. Select **Power Off Control** using the ▲/▼ button.
2. Select either Enable or Disable the **Power Off** Control using the **OK** (OK) or ► button.

**Enable** Uses the Power Off Control and sets the Power Off time.

**Disable** Not uses the Power Off Control.

3. When you have selected **Enable**, enter the **Time** using the **NUMERICAL** (0-9) buttons, and select **OK**, and press the **OK** (OK) button.

**Note:** Once Power On/Off Control is specified, it is repeated everyday.

## 7.4 Schedule

You can reserve a programme to watch programme at your desired time.

1. Press the **MENU** (Ⓜ) button.
2. Select **Preferences** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
3. Select **Schedule** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
4. **Reserved Programme list** is displayed on the screen. To edit the existing reservation, select your desired reservation, and press the **OK** (Ⓞ) button. To add a new reservation, select a blank list and press the **OK** (Ⓞ) button.



### Note:

- For detailed information about how to edit or add a reservation, refer to **Chapter 6 Programm Guide**.
- This menu is enabled only for the product without hard disk drive.

## 7.5 A/V Control

You can set Audio or Video Output Control.

1. Press the **MENU** (Ⓜ) button.
2. Select **Preferences** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
3. Select **AV Control** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button



### 1. TV - SCART

You can set TV SCART Output.

1. Select **TV-SCART** using the **▲/▼** button, and press the **OK** (Ⓞ) or **▶** button.
2. Select one option among **CVBS/RGB** using the **▲/▼** button, and press the **OK** (Ⓞ) button.

### 2.VCR-SCART

The receiver doesn't provide this function.

## 7. Setting Preferences

### 3. Screen Ratio

You can set the aspect ratio of your TV.

1. Select **Screen Ratio** using the  $\blacktriangle/\blacktriangledown$  button.
2. Select one option from **4:3** or **16:9** using the **OK** (OK) or  $\blacktriangleright$  button.

### 4. Display Format

You can select the Display Format according to TV Screen Ratio.

1. Select **Display Format** using the  $\blacktriangle/\blacktriangledown$  button, and press the **OK** (OK) or  $\blacktriangleright$  button.
2. If the Screen Ratio is set to **4:3**, you can select one from **Auto/Letter box/Center box** using the  $\blacktriangle/\blacktriangledown$  button, and press the **OK** (OK) button.
3. If the Screen Ratio is set to **16:9**, you can select one from **Auto/Pillar box/Full mode** using the  $\blacktriangle/\blacktriangledown$  button, and press the **OK** (OK) button.

### 5. TV Standard

You can select the TV Standard: PAL or NTSC.

1. Select **TV Standard** using the  $\blacktriangle/\blacktriangledown$  button, and press the **OK** (OK) or  $\blacktriangleright$  button
2. Select one option among **Auto/PAL/NTSC** using the  $\blacktriangle/\blacktriangledown$  button, and press the **OK** (OK) button.

**AUTO** The TV supports both PAL and NTSC.

**PAL** The TV supports only PAL.

**NTSC** The TV supports only NTSC.

### 6. NTSC Mode

If TV Standard is set to NTSC, set the following mode.

1. Select **NTSC Mode** using the  $\blacktriangle/\blacktriangledown$  button.
2. Select one option from **3.58/4.43** using the **OK** (OK) or  $\blacktriangleright$  button.

### 7. Audio Output

Set the Audio Output.

1. Select **Audio Output** using the  $\blacktriangle/\blacktriangledown$  button.
2. Select one option form **Stereo** or **Mono** using the  $\blacktriangle/\blacktriangledown$  or **OK** (OK) button.

## 7.6 UHF

This receiver doesn't provide this function.

## 7.7 Miscellaneous

1. Press the **MENU** (Ⓜ) button.
2. Select **Preferences** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button.
3. Select **Miscellaneous** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button.



### 1. i-Plate Display Time

You can set the duration during which the Information box is to be displayed when you switch the channel.

1. Select **i-Plate Display Time** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button.
2. Select a value between 0 ~ 20 seconds using the ▲/▼ button, and press the **OK** (Ⓞ) button.

**Note:** When it is set to '0', the i-Plate will not be displayed when you switch the channel.

### 2. OSD Transparency

You can set the transparency of On Screen Display.

1. Select **OSD Transparency** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button.
2. Select one option among **Disable/25/50/75** using the ▲/▼ button, and press the **OK** (Ⓞ) button.

**Disable** Fully opaque screen

**25, 50, 75** As the number is bigger, the screen is more transparent.

### 3. Option in Channel List

This receiver doesn't provide this function.

## 8. Installation

This chapter describes how to search for channels and a series of procedures.

### 8.1 Antenna Setting

You can set Antenna and LNB Information channel search. If antenna is not correctly set, you cannot search channel, therefore, you cannot watch a programme, either.

1. Press the **MENU** (Ⓜ) button.
2. Select **Installation** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button.
3. Password is required to use Installation Menu. Enter Password to directly move to Installation Menu.



4. Select **Antenna Setting** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button to enter Antenna Setting.

**Note:** If no satellite is registered from Antenna Setting menu, Channel Search such as **Automatic Search, Manual Search, Multiple Manual Search, Advanced Search, Antenna Setting** is not available.



### Satellite

You can select satellite for Channel Search.

1. Select **Satellite** using the ▲/▼ button, and press the **OK** (Ⓞ) or ► button.
2. Select the satellite that is the antenna heads for from the alphabetically sorted satellite list using the ▲/▼ button, and press the **OK** (Ⓞ) button.



3. If no desired satellite exists in the list, select User Define Satellite item. When you are prompted to select whether or not to edit User Define Satellite, select **Yes**, and press the **OK** (Ⓞ) to display keyboard to edit the Name. Enter Satellite Name directly, select **OK** and press the **OK** (Ⓞ) button.



## Satellite Alternative

You can search and watch a programme by using the antenna headed for the selected satellite.

1. Select **Satellite Alternative** using the ▲/▼ button, and press the OK (OK) or ► button.
2. Then, you can change into one of the following options.

**Disable** Does not search the selected satellite.

**Enable** Searches the selected satellite.

**Note:** If there is no satellite that Satellite Alternative is set to **Enable**, Channel Search is not available.



## LNB Frequency (MHz)

You can enter LNB Frequency.

1. Select **LNB Frequency** using the ▲/▼ button, and press the OK (OK) or ► button.
2. Select one value from **Universal, 9750, 10600, 5150, 11475, User Define** using the ▲/▼ button. If you have selected **User Define**, enter LNB Frequency value directly, and press the OK (OK) button.

**Note:** If you have selected **Universal**, select **9750/10600**. In this case, the **22KHz tone** value is **disabled**.



## 22kHz Tone

You can select whether or not to use 22KHz Tone.

1. Select **22kHz Tone** using the ▲/▼ button.
2. Select whether or not to use 22KHz Tone using the ▲/▼ or OK (OK) button.

**Enable** Selects **Enable** if Dual LNB is used or 2 antennas are connected to the 22kHz tone switch box.

**Disable** Selects **Disable** if 22kHz Tone is not used.



## 8. Installation

### DiSEqC Input

You can select DiSEqC switch.

1. Select **DiSEqC Input** using the ▲/▼ button, and press the **OK** (OK) or ► button.  
Select the **DiSEqC Switch** using the ▲/▼ button, and press the **OK** (OK) button.  
You can select one option among **Tone burst A~B**, **DiSEqC A~D**, **DiSEqC A~D for 2.0** and **Disable**.



### LNB Voltage

This receiver doesn't provide this function.

## 8.2 Automatic Search

If you select the satellite to search channel according to the Antenna Setting, you can automatically search the satellite without entering any other information. And you cannot watch any programme without searching channel.

1. Select **MENU** (MENU) button.
2. Select **Installation** using the ▲/▼ button, and press the **OK** (OK) or ► button.
3. Select **Automatic Search** from Installation menu using the ▲/▼ button, and press the **OK** (OK) or ► button.



## Satellite

You can select which satellite to search the channel.

1. Select **Satellite** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select one of satellites using the ▲/▼ button, and press the **OK** (OK) button.



**Note:** Channel Search is performed only for the satellites that have been set to **Enable** in Antenna Setting-Satellite Alternative menu. If you wish to search channels for satellites, which is not listed on the Satellite List of Automatic Search, move to **Antenna Setting** and set the Satellite Alternative item as **Enable**.

## Scrambled Type

You can set scrambled type to search by free channel.

1. Select **Scrambled Type** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select **All or Free**, using the ▲/▼ button, and press the **OK** (OK) button.

**All** Searches all channels.

**Free** Search only free channels.



## Channel Type

You can search by TV or Radio channel.

1. Select **Channel Type** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select one option among **All**, **TV** and **Radio** using the ▲/▼ button.

**All** Searches all channels.

**TV** Search only TV channels.

**Radio** Searches only Radio Channel.



# 8. Installation

## Search

You can complete the setting and start searching.

1. Select **Search**, and press the **OK** (OK) button to start Automatic Search.
2. During operating search, the cursor is located at **Stop**. Therefore, if you press the **OK** (OK) button during searching, the operation is stop and the channels found until then will be displayed.
3. Even if search operation is completed, and the channel does not exist, press the **OK** (OK) button and try to reset the search operation again if necessary.
4. You can delete unnecessary channels from the searched channels. Select your desired channels to delete and press the **OK** (OK) button. Then select **Delete** and press the **OK** (OK) button. To delete all channels, select **Select All** to select all channels, select **Delete**, and press the **OK** (OK) button.
5. When completing Channel Search and deleting unnecessary channels, select **Save** to save the changes.



## 8.3 Manual Search

You can search channels of the selected satellites by transponders if you know the Transponder information.

### 1. Satellite

Selects a satellite to search from the satellites set in Antenna setting.

1. Select **Satellite** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.
2. Select one of the Satellite names to search channel using the **▲/▼** button, press the **OK** (OK) button.

**Note:** If the satellite scheduled to search channel is not exist in the Satellite list, move to Antenna Setting menu, set Antenna for the Satellite, and then try again.



## 2. Transponder

Sets transponder value for the satellite

1. Select **TP** using the ▲/▼ button and press the **OK** (OK) or ► button.
2. Select one value from the transponder value using the ▲/▼ button, and press the **OK** (OK) button.
3. If you cannot find your desired Transponder information from the Transponder List, select **User Define**, and press the **OK** (OK) button to change the Transponder information as follows.

- Enter Transponder frequency using the **NUMERICAL** (0~9) buttons.
- Select **Polarisation** and press the **OK** (OK) or ► button to select one option among **Auto/Horizontal/Vertical**.  
**Note:** Horizontal outputs 18V, and Vertical outputs 13V through LNB line.
- Select **Symbol Rate (ks/s)** and press the **OK** (OK) or ► button to select one Symbol Rate value from **27500/26000/22000**. If your desired value does not exist, select **User Define** to enter Symbol Rate value directly using the **NUMERICAL** (0~9) buttons.
- Select **FEC (Forward Error Correction)** option and press the **OK** (OK) or ► button to select one option among **Auto, 1/2, 2/3, 3/4, 5/6, and 7/8**.
- When completing entering Transponder information, select **Done** and press the **OK** (OK) button to finish entering User Define Transponder value.



### Note:

- For channel transponder information, you can find your desired information from Satellite channel magazine, Satellite channel related home pages, news release and home page of broadcasting company, etc.
- If you have correctly completed setting the Transponder information, Strength bar and Quality bar should represent as High. If the Level is close to 0, please try to reset.

## 8. Installation

### 3. Network Search

If your desired transponder provides the information of other transponder, you can determine whether or not to search the channel for other transponder.

1. Select **Network Search** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select either **Enable** or **Disable** and press the **OK** (OK) button. Select **Enable** to run Network Search.



### 4. Scrambled Type

You can determine whether or not to search channel by free.

1. Select **Search Type** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select one option among **All**, **Free** and **CAS** using the ▲/▼ button, and press the **OK** (OK) button.

**All** Searches all channels.

**Free** Searches only Free Channel.



### 5. Channel Type

You can search by TV or Radio Channel.

1. Select **Channel Type** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select one option among **All**, **TV** and **Radio** using the ▲/▼ button.

**All** Searches all channels.

**TV** Searches only TV Channel.

**Radio** Searches only Radio Channel.



### 6. Search

You can complete the setting and start searching.

1. Select **Search** and press the **OK** (OK) button to start Manual Search.
2. The next procedures are the same as those of Automatic Search. Please refer to Automatic Search.

## 8.4 Other Search

You can directly enter the Packet ID value or find how to search channel using SMATV. And you can search channel for several transponders at one time.

1. Press the **MENU** (MENU) button to run **Menu**.
2. Select **Installation** using the ▲/▼ button, and press the **OK** (OK) or ► button.
3. Select Other Search, and press the **OK** (OK) or ► button. Press the **BACK** (BACK) or ◀ button to return to the previous menu.

### 1. Advanced Search

You can find your desired channel by entering Video, Audio and PCR Packet ID directly In Other Search Menu, Select **Advanced Search** using the ▲/▼ button, and press the **OK** (OK) or ► button to start Advanced Search.

### Satellite, Transponder

The setting for satellite and transponder is the same as that of Manual Search. Refer to the satellite and transponder setting for Manual Search.

### Video PID, Audio PID, PCR PID

You can enter the PID value for specific channel.

1. Select the **PID** to set using the ▲/▼ button, and press the **OK** (OK) or ► button.

**Video PID** Enter the Video PID value.

**Audio PID** Enter the Audio PID value.

**PCR PID** Enter the PCR PID value.

2. Set **PID value**.

**Auto** Search PID value automatically.

**Hexadecimal** Enter PID value in Hexadecimal numeric.

**Decimal** Enter PID value in Decimal .

3. When you have select **Hexadecimal** or **Decimal**, enter PID value directly using Keyboard.
4. When completing entering PID value, select **OK**, and press the **OK** (OK) button.



# 8. Installation

## Search

You can complete setting and start searching.

1. Select **Search** and press the **OK** (OK) button to start Advanced Search.
2. The next procedures are the same as those of Automatic Search. Please refer to Automatic Search.

## 2. SMATV Search

If your receiver uses the antenna for common use, operate SMATV Search. For SMATV Search, Channel Search is performed by the antenna for common use regardless of the setting value in Antenna Setting.

Select **SMATV Search** in Other Search Menu using the **▲/▼** button, and press the **OK** (OK) or **▶** button.

## Frequency

1. Select **Frequency** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.
2. Enter the down converted frequency through common LNB. You can enter the frequency between 950 and 2150 MHz.



## Polarisation

1. Select **Polarisation** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.
2. Select one from **Disable/Auto/Horizontal/Vertical** and press the **OK** (OK) button.

**Note:** Horizontal outputs 18V, and Vertical outputs 13V through LNB line. Select Disable when LNB Power is not necessary.



## Symbol Rate

1. Select **Symbol Rate** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.
2. Select the symbol rate of the transponder. If the rate does not exist in the list, select



## FEC

1. Select **FEC** using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Select one option among **Auto, 1/2, 2/3, 3/4, 5/6, 7/8**, and press the **OK** (OK) button.



## Search

You can complete setting and start searching.

1. Select **Search** and press the **OK** (OK) button to start SMATV Search.
2. The next procedures are the same as those of Automatic Search. Please refer to Automatic Search.

## 3. Multiple Manual Search

If you wish to search multiple transponder at the same time, you can run Multiple Manual Search. This function is useful when repeating Manual Search.

1. Select **Multiple Manual Search** from Other Search Menu using the ▲/▼ button, press the **OK** (OK) or ► button to enable the Multiple Manual Search.
2. Select one option among **Satellite, Edit TP List, Search Type, Scrambled Type** using the ▲/▼ button, and press the **OK** (OK) or ► button.
3. Set the selected item.

**Note:** Settings for Satellite, Search Type, and Channel Type are the same as those of Manual Search. Refer to Manual Search.



## 8. Installation

### Edit TP List

You can edit TP list to search at a time and change the setting for Transponder.

1. Select **Edit TP List** from **Multiple Manual Search**, and press the **OK** (OK) or **▶** button.
2. Select **Add** and press the **OK** (OK) button to add a new Transponder data.
3. Select a specific transponder from the **transponder list**, press the **OK** (OK) button, select **Edit**, and then press the **OK** (OK) button to edit Transponder data.
4. Select a specific transponder from the **transponder list**, press the **OK** (OK) button, select **Delete**, and then press the **OK** (OK) button to delete Transponder data. You can select multiple TPs to delete.
5. When completing configuring **transponder list**, select **Save** and press the **OK** (OK) button to save the result and exit.

**Note:** When you select **Default List** and press **OK** (OK) default transponder list is displayed.



## 8.5 Default Setting

Default Setting restores the receiver to the default settings.

**Warning:** Please note that once you perform Default Setting, all data such as Antenna Setting information Channel List, and User Configured data are deleted.

To perform Factory Default:

1. Press the **MENU** (MENU) button.
2. Select **Installation** using the ▲/▼ button, and press the **OK** (OK) or ► button.
3. Enter **password** using the **NUMERICAL** (0-9) buttons.
4. Select **Default Setting** using the ▲/▼ button, press the **OK** (OK) or ► button.
5. Select **Yes** and press the **OK** (OK) button to restore all settings to Factory Default. Select **No** and press the **OK** (OK) or **BACK** (BACK) button to return to the previous menu.
6. Confirm again to start loading default setting. Enter **password** using the **NUMERICAL** (0-9) buttons to perform restoring.
7. When completing the default setting, press the **OK** (OK) button to automatically run the **Installation Wizard**. When default setting is completed, Installation Wizard is automatically displayed, which helps Channel Search. For detailed information about Installation Wizard, refer to **3. Installation Wizard**.



## 9. Software Upgrade

In order to maintain proper performance of this product, it is essential to have the most up-to-date software. The latest news and release of software versions may be found at the Humax website - <http://www.humaxdigital.com>.

It is recommended that you periodically check for the availability of software upgrades.

### 9.1 OTA (Over the Air)

OTA, an abbreviation of "over-the-air", means that downloads the software can be downloaded where the manufacturer reserves the right to decide when and where to release through Antenna system.

Over the Air(OTA) is simply an alternative method for downloading software versions. However, the manufacturer reserves the right to decide when and where this software update can take place by "beaming" latest software versions over the air via antenna systems. Note that OTA is only limited to certain geographical regions mainly due to different antennas having different footprints(area where the signal can be received). The software update via satellite system will only occur under the following circumstances.

1. The equipment should have appropriate loader software.

**Caution:** Please note that if you don't have normal loader software, the equipment may not be updated or work after software update.

2. The manufacturer decides to release software downloading via a designated antenna system
3. The equipment must be **tuned** properly to the same antenna that the manufacturer uses.
4. Upgrade software when the quality of receiving signal strength is high. If the weather is not so good that the quality of receiving signal strength is not recommendable, perform the software upgrade later.

#### Caution:

- Please be careful to keep the power on and the power cord plugged in during software update. If the power is off during software update, it may cause fatal damage to the product.
- Please be careful not to pull out the signal line (LNB Cable) during software update. Update may be interrupted and the product may not work.

#### Note:

- The other functions of product cannot work at all during software update.
- It may take 5 ~10 minutes to update software.
- Scheduling operation cannot work during software update.

## 1. If new software is found when powering on

1. A message will be displayed to notify that new software is found.
2. Select **Yes** and press the **OK** (OK) button to update the software.
3. Starts downloading new software. Please wait until the updated is completed.
4. When completing the software update, the equipment is automatically powered off and on again.

## 2. If updating software from Menu

1. Press the **MENU** (MENU) button.
2. Select **Installation** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.
3. Enter **Password** using the **NUMERICAL** (0-9) buttons.
4. Select **Software Upgrade** using the **▲/▼** button, and press the **OK** (OK) or **▶** button.



### If new version of software is detected during watching a programme

1. A message will be displayed to notify that new software is found.
2. Select **Yes** and press the **OK** (OK) button to start upgrading. Select **No** and press the **OK** (OK) button to return to the previous menu.



# 9. Software Upgrade

## If using Automatic Update

You can set the product to find HUMAX software update site and update software automatically.

1. Select **Automatic** from **Software Update Menu** screen using the ▲/▼ button, and press the **OK** (OK) or ► button.
2. Automatically search for new software.
3. When detecting update software, the following result is displayed. If new software is not found by Automatic, use Manual Update.
4. Select **Yes** and press the **OK** (OK) button to start updating. Select **No** and press the **OK** (OK) button to return to the previous menu without updating.
5. When completing the software update, the product is automatically powered off and on again.



**Note:** Software Update Sites of HUMAX are listed in the following table.

Satellite	Transponder data
Astra1	12669 (V) 22000 5/6
Sirius	12054 (V) 27500 3/4
Hispasat	11811 (H) 27500 3/4
Nilesat	11765 (H) 27500 3/4
Hotbird	11623 (V) 27500 3/4

Among the Software Update Sites of HUMAX, the software search operation is performed only for the satellites that have been set to **Enable** in **Installation - Antenna Setting- Satellite Alternative** menu and that have all other Antenna Setting correct.

## Manual Update

You can perform Manual Update only if you know which satellite has new software and the Transponder information correctly.

1. Select **Manual Update** from **Software Update** screen using the ▲/▼ button, and press the **OK** (OK) or ► button.  
Select the the Satellite which provides update software. Satellite list contains the satellites that have been set to **Enable** in **Installation - Antenna Setting- Satellite Alternative** menu. For unlisted satellite, start with Antenna Setting.
2. Enter Transponder Frequency in which updated software is provided.
3. Enter **Polarisation value**.
4. Select **Symbol Rate value**. If it is not found in the List, select User Define and enter manually.
5. Select **FEC value**.

**Note:** How to set Satellite and Transponder for Manual Update Sites is the same as how to edit User Define Transponder data in Manual Search. Refer to Manual Search.

6. Select **Search** and Press the **OK** (OK) button to search software.
7. It is displayed whether or not New Software exist. If new software does not exist, press the **OK** (OK) button to return to the Manual Update Menu.
8. Select **Yes** and press the **OK** (OK) button to start updating. Select **No** and press the **OK** (OK) button to return to the previous menu.
9. Performs Software Update. Please wait until it is completed.
10. When completing the software update, the product is automatically powered off and on again.



# 9. Software Upgrade

## 9.2 Software Update from PC

You can connect your receiver to the PC directly and update your software by transferring the new software from the PC. Follow these steps to download new software from PC to this product.

1. Download new software file (HDF files) equivalent for this product model from our website into your computer(<http://www.humaxdigital.com>).
2. Download and install download tool from our website into your computer.
3. Connect your PC to this product with RS-232C serial cable.
4. Execute installed download tool, and then follow the instructions contained the download tool.
5. Press the **STANDBY** (⏻) button to make this product operating.



# 10. System Information

You can view all system information, signal strength, and Common Interface information.

1. Press the **MENU** (☰) button.
2. Select **System** using the ▲/▼ button, and press the **OK** (⊙) or ► button.



## 10.1 Status

You can view System information

1. Select **Status** using the ▲/▼ button, and press the **OK** (⊙) or ► button.
2. Confirm the information about **Hardware version**, **Software version**, **Loader version**, **System ID**, **Slot1**, **Slot2**.



## 10.2 Signal Detection

You can view the signal strength and signal quality receiving from satellite via your satellite dish.

1. Select **System Detection** using the ▲/▼ button, and press the **OK** (⊙) or ► button.
2. Display information about the satellite and transponder, which current channel belongs to and the graphs and percentage of Signal Strength and Quality of the channel.



# 11. Games


This product provides various games for user's entertainment.

1. Press the **MENU** (MENU) button.
2. Select **Game** using the ▲/▼ button, and press the **OK** (OK) button.
3. According to the instruction displayed on screen, you can enjoy the game using ▲/▼/◀/▶ and **OK** (OK) button.

## Note:

- **Game** menu is available only for the product without hard disk drive. You can enjoy a game for the product with hard disk drive using the (G) button at remote controller.
- Press the **EXIT** (EXIT) or **BACK** (BACK) button to exit the game.

## 12. Menu Map



# 13. Trouble Shooting

## 13.1 Trouble Shooting

Before contacting your local service, please make sure following instructions. If the product does not work normally after completing the following trouble shooting, please contact your local product distributor or service centre.

1. No message is displayed on the front panel or product has no power.
  - Check the main power cable and check that it is plugged into a suitable power outlet.
  - Check whether the Power Switch is On.
2. No picture
  - Make sure that the product is in Operation Mode.
  - Make sure that the AV Cable is firmly connected to the TV.
  - Make sure that Antenna line is correctly connected to the equipment.
  - Make sure that Antenna Setting is correct.
  - Check the brightness level of TV.
  - Check the channel is on air.
3. Poor picture and sound quality
  - Install the antenna in a place where there is no obstacle.
  - Make sure there is no mobile phone or microwave oven near the equipment.
  - Use 75  $\Omega$  coaxial cable to connecting TV and antenna.
  - Keep the product and the antenna cable for satellite far away from each other.
  - Make sure the receiving level, and adjust antenna if the level is low. The receiving level can be influenced by weather.

**Note:** If the CS Antenna is covered with snow or the RF is weaken by heavy rain, sound and picture may temporarily be poor. However, these poor sound and picture quality because of weather conditions cannot be not accepted as a malfunction of equipment.

  - Change satellite dish into bigger one if satellite dish is small.
  - Replace LNB with the one with low noise factor if the noise factor is high.
  - Replace LNB with new one if it is damaged or out of order.
4. No or poor sound
  - Check the volume level of the TV and Receiver.
  - Check the Mute status of the TV and product.
  - Press the Audio button to change the Sound Track type.
5. Remote controller does not operate
  - To control the equipment with the remote controller, the remote controller's top end should directly point towards the receiving part of receiver's remote controller.
  - Check the battery of Remote controller.
6. Reservation is unavailable
  - Check whether it it not overlapped with other reservation.
  - Check whether the power switch is off.

## 13.2 Error Message

Error message	Possible causes	What to do
No or bad signal	The satellite dish is not pointing at the satellite. Signal too weak. Satellite dish is too small. LNB is faulty. Wrong antenna setting.	Adjust dish. Increase the LNB voltage or connect a signal amplifier. Change to a large dish. Change the LNB. Set the antenna correctly
The audio is not available.	The channel has signal, but no Audio.	Press the Audio button to confirm if the channel has Audio.
LNB short	LNB cable is shorten. LNB is internally shorten. LNB In Port is inserted by alien substance or damaged.	Replace LNB Cable. Replace LNB. Remove the alien substance and contact local service center if it is damaged.

## 14. Specification

Tuner and Channel	
Input Connector	F-type, IEC-169-24, Female
Frequency Range	950MHz to 2150MHz
Signal Level	-20 to -75dBm
LNB Power and Polarisation	Vertical: +13.5V (+14.5V at high voltage) Horizontal: +18V (+19V at high voltage) Current: 500mA Max. Overload Protection
22kHz Tone	Frequency: 22±4kHz Amplitude: 0.6±0.2V
DiSEqC Control	Version 1.0/1.2 Compatible, USALS
Demodulation	QPSK
Input Symbol Rate	1~45 Ms/s
FEC mode	Convolutional Code Rate 1/2, 2/3, 3/4, 5/6 and 7/8 with Constraint Length K=7
MPEG Transport Stream A/V Decoding	
Transport Stream	MPEG-2 ISO/IEC 13818 Transport Stream Specification
Profile Level	MPEG2 MP@ML
Video Input Rate	15 Mbit/s Max
Aspect Ratio	4:3, 16:9 , Letter box
Video Resolution	720x576, 720x480
Audio Decoding	MPEG/MusiCam Layer I and II
Audio Mode	Single channel/Dual channel/Joint Stereo/Stereo
Memory	
Flash Memory	2M byte
Graphic (MPEG) and System DRAM	8M byte
EEPROM	8K byte

<b>RF Modulator</b>	
RF Input/Loophrough output	75Ω, IEC169-2
Frequency	470~862 MHz
Output Channel	CH 21~69
TV Standard	PAL B/G/I/D/K
<b>A/V and Data In/Out</b>	
Video	RCA/SCART Video Output (CVBS, S-Video)
Audio R/L	RCA/SCART Volume and Mute Control (Resolution: 20 bits DAC, MAX, 2Vrms)
S/PDIF	Digital Audio Output, Fiber-Optic (Resolution: 20 bits)
RS-232C	Transfer Rate:115,200bps, 3 pin Socket type
<b>Power Supply</b>	
Input Voltage	90~250V AC, 50/60Hz
Type	SMPS
Power Consumption	Max. 31W without hard disk drive Max. 40W with hard disk drive
Stand by Power	≤8W
Protection	Separate Internal Fuse. The input should be protected against lightning
<b>Physical Specifications</b>	
Size	370 * 60 * 262 mm
Weight (Net)	Around 3.8Kg
Operating Temp	0°C to + 45°C
Storage Humidity	5% ~ 95% RH (Non-Condensing)

## 15. Glossary

### **DiSEqC (Digital Satellite Equipment Control)**

A standard through which it is possible to let a DiSEqC compatible receiver send a signal over the RF cable to a switching device to switch between different LNBs or dishes. The DiSEqC uses the 22KHz signal to control the switching device.

### **Programme Guide (Electronic Programme Guide, EPG)**

A electronic program guide (EPG) that comes with the broadcast to a particular satellite, note that every station fills the EPG differently or not, so differences in the EPG are not necessarily receiver errors.

### **Frequency**

The number of cycles or events per one second, which is expressed in the unit of hertz.

### **FTA (Free-To-Air)**

An unscrambled broadcast, which you can view without additional payments to a service provider.

### **Hi-Fi (High Fidelity)**

The characteristics of audio devices that can play back all the audio frequencies of the human, which is the range of 16Hz~20KHz, uniformly from the low frequency to high frequency. Sometimes it is used to indicate good quality of an audio device such as stereo tape recorder.

### **LNB (Low Noise Block)**

An electronic unit mounted on the satellite dish. It receives the signals reflected by the dish and converts them to signals that can be used by this product.

### **OSD (On Screen Display)**

The function that displays the information about the monitor that the user needs or has to know on the screen directly. OSD information includes brightness, contrast, tuning, RGB adjustment, and screen size and positions (top, left, width, and height), and so on.

### **OTA (Over The Air)**

Means that software downloads where the manufacturer reserves the right to decide when and where to release them through satellite system.

### **Transponder**

An automatic device that receives amplifies and retransmits a signal on a different frequency.

## 16. Service and Support

You can get information such as a troubleshooting guide, software upgrades and product support guide from the following web sites and call center (Hotline).

Please try to contact to your local dealers first when you have any problem.

### Web site and e-mail

#### Homepage

<a href="http://www.humaxdigital.com">http://www.humaxdigital.com</a>	English
<a href="http://www.humaxdigital.com/Deutsch/">http://www.humaxdigital.com/Deutsch/</a>	Deutsch
<a href="http://www.humaxarabia.com">http://www.humaxarabia.com</a>	Arabic

#### HCSA (Humax Customer Service Area)

Software Download, Information and Technical Q&A

<a href="http://www.humaxdigital.com/hcsa/">http://www.humaxdigital.com/hcsa/</a>	English
<a href="http://www.humaxdigital.com/Deutsch/hcsa/">http://www.humaxdigital.com/Deutsch/hcsa/</a>	Deutsch

#### E-mail (Technical Q&A)

<a href="mailto:tech-info@humax-digital.co.uk">tech-info@humax-digital.co.uk</a>	Europe & North Africa
<a href="mailto:techinfo@humax-digital.de">techinfo@humax-digital.de</a>	Germany
<a href="mailto:callcenterME@humaxdigital.com">callcenterME@humaxdigital.com</a>	Middle East
<a href="mailto:Webmaster@humaxdigital.com">Webmaster@humaxdigital.com</a>	Asia & Other area

# 16. Service and Support

## Call Center

### Humax Middle East Call Center (Dubai, UAE)

Tel: +971 (0)4 359 2323 (Open: 9:00 - 20:00 / close on Friday)

E-mail: callcenterME@humaxdigital.com

Open: Local Time in Dubai (GMT+4)  
9:00 - 20:00 (Saturday - Thursday, close on Friday)

Support Language: English/Arabic

### Humax Hotline (Germany)

Germany: 01805 778 870 (€ 0,12/Min)

Other Countries: + 49 1805 778 870 (€ 0,12/Min+ International Call Charge)

Open: Local Time in Germany (GMT+1)  
8:00 - 20:00 (Monday - Friday)  
8:00 - 18:00 (Saturday)

Support Language: Deutsch/English

### Humax BTCL Hotline (Premiere Model)

Germany: 01805-778900 (€ 0,12/Min)

Austria: 0900-900633 (€ 0,33/Min)

For hardware repair, please refer to support website. (Homepage or HCSA)